





F.. SERIES

Parallel Shaft Gearmotors





K../S../W.. SERIES

Right-Angle Gearmotors




R.. SERIES

Inline Gearmotors



Motor Conduit Box and Cable Entry Positions



Brake Hand Release Locations

Midwest Region
SEW-Eurodrive, Inc
2001 West Main St.
Troy, OH 45373
P: (937) 335-0036
cstroy@seweurodrive.com

Northeast Region
SEW-Eurodrive, Inc
2107 High Hill Rd.
Bridgeport, NJ 08014
P: (856) 467-2277
csbridgeport@seweurodrive.com

Southeast Region (U.S. HQ)
SEW-Eurodrive, Inc
220 Finch Rd.
Wellford, SC 29385
P: (864) 439-7537
cslyman@seweurodrive.com

Southwest Region
SEW-Eurodrive, Inc
202 W. Daniieldale Rd.
DeSoto, TX 75115
P: (214) 330-4824
csdallas@seweurodrive.com

Western Region
SEW-Eurodrive, Inc
30599 San Antonio St.
Hayward, CA 94544
P: (510) 487-3560
cshayward@seweurodrive.com

Large Industrial Gearing
SEW-Eurodrive, Inc
148 Finch Rd.
Wellford, SC 29385
P: (864) 439-8792
igssorders@seweurodrive.com